



SOCCER BALL INFLATING INSTRUCTIONS:

1. REMOVE WHITE PLUG FROM SOCCER BALL.
2. GRASP PLUG AND PULL STRAIGHT OUT.
3. REPLACE AFTER INFLATING SOCCER BALL.
4. USE AIR COMPRESSOR TO INFLATE BALL.
5. INFLATE BALL TO A MAXIMUM OF 45 INCHES.
6. DO NOT OVER INFLATE. OVER INFLATING WILL CAUSE BALL TO BURST.
7. WHEN NOT IN USE FOR A PERIOD OF TIME IT IS RECOMMENDED
DEFLATE BALL AND STORE IN COOL DARK PLACE

CAUTION:

DO NOT under inflate ball or leave soft, if too soft Horse can step on or bite the ball this will cause the ball to puncture or tear.

DO NOT leave ball unattended in arena with horses.

DO NOT hit ball with any kind of stick or bat during games.

FOR FURTHER QUESTIONS: EMAIL: jakesplace@mchsi.com